

Standard length



Chrome shocks for Softail 1986-99

**Lowering style:
14-0210 Standard load
14-0211 Heavy load**

Lowering shocks:

1986-1999 shocks:

For lowering adjustment, adjust both lowering head (2) to same length, (only before install shock on to bike) then tighten nut (1). Normally, every inch extended, will lower bike by 3 inch, (ratio 1:3),



2000-up Lowering kit



2000-up rear shocks w/lowering

Lowering shocks

2000-up shocks:

Loose nut (2), adjust nut (1) away from shock body to same length, then tighten nut (1) counterclockwise, lowering ratio: 1:3